

Changing various settings

Setting the auto save function

Enable parameters to be saved automatically.

- On the SETUP screen, turn  to select AUTO SAVE.



- Press .



- Turn  to set AUTO SAVE to ON/OFF.



NOTE

When set to OFF, no patch or effect parameters will be saved automatically.



- Press  to confirm the auto save setting.



Note about switching patches

When AUTO SAVE is set to OFF, if you try to switch patches after changing any parameters, a message will appear asking to save the parameter changes.

To save changes to parameters before switching patches, select YES. (→P19)

To discard changes to parameters before switching patches, select NO.

Adjusting the display contrast

- On the SETUP screen, turn  to select LCD CNTRST.




- Press .




- Turn  to select a display to adjust its contrast.



- Press  to confirm the display.



- Turn  to adjust the contrast.



NOTE

The setting range is 1-13.



- Press  to confirm the contrast setting.



Using the tuner

Activating the tuner

- Press and hold  in STOMP or MEMORY mode.



- Press  or .



The BYPASS sound is output when the TUNER is active.



No sound is output when the TUNER is active.



- This opens the TUNER screen.



Tuning a bass guitar

- Play the open string that you want to tune and adjust its pitch.


Chromatic tuner

The name of the nearest note and the pitch accuracy are shown.




Other tuners

The number of the nearest string and the pitch accuracy are shown.




Closing the tuner

- Press  when the TUNER screen is open.


Using the tuner

Changing the tuner settings

■ Opening the TUNER SETTINGS screen

- Press  to open the MENU screen.




- Turn  to select TUNER.



- Press  to open the TUNER SETTINGS screen.



■ Changing the standard pitch of the tuner

- On the TUNER SETTINGS screen, turn  to select CALIBRATION.



- Press .




- Turn  to change the standard pitch.



NOTE

The setting range is 435–445 Hz for middle A.



- Press  to confirm the standard pitch of the tuner.




HINT

You can also turn the center unit  when the TUNER screen is open to change the standard pitch.

Using the tuner


■ Changing the tuner type

- On the TUNER SETTINGS screen, turn  to select TYPE.



- Press .



- Turn  to select the tuner type.



CHROMATIC

The chromatic tuner shows the nearest pitch name (semitone) and how far the input sound is from that pitch.


Tuner type

Display	Meaning	String number/Note name					
		LB	4	3	2	1	HC
BASS	Standard tuning for bass guitars, including those with 5 or 6 strings	B	E	A	D	G	C

HINT


"LB" is the low B string and "HC" is the high C string.



- Press  to confirm the tuner type.




■ Using flat tuning

- On the TUNER SETTINGS screen, turn  to select FLAT.



- Press .



- Turn  to change the flat tuning.



NOTE

- You can drop the tuning by one (x 1), two (x 2) or three (x 3) semitones.
- Drop tuning is not possible when the TYPE is set to CHROMATIC.




- Press  to confirm the flat tuning setting.



Using rhythms

Selecting a rhythm

- Press  to change to STOMP mode.



- Use  TYPE  to select RHYTHM for the desired unit.



NOTE

One RHYTHM can be selected per patch.

Playing a rhythm

- Press  for the unit using the rhythm effect.



- The rhythm starts playing.



HINT

- During rhythm playback, you can switch between STOMP and MEMORY modes.
- If you change a patch during rhythm playback, the rhythm will stop.

Stopping a rhythm

- During rhythm playback, press  for the unit using the rhythm.




- The rhythm stops.



Setting rhythms

■ Selecting rhythm patterns


- Turn  for the unit using the rhythm.



NOTE

See P46 for information about the patterns.

■ Adjusting the rhythm tempo

- Turn  for the unit using the rhythm.



NOTE

- The setting range is 40–250 bpm.
- This tempo setting is used by every effect, rhythms and the looper.

■ Adjusting the rhythm volume

- Turn  for the unit using the rhythm.




NOTE



The setting range is 0–100.

Using the looper

Selecting the looper

- Press  to change to STOMP mode.



- Use  **TYPE**  to select a LOOPER for the desired unit.

1-unit looper



2-unit looper




NOTE

- There are 4 types of loopers: 1-unit mono, 2-unit mono, 1-unit stereo and 2-unit stereo.
- One LOOPER can be selected per patch.

Recording, playing and clearing phrases

■ Recording phrases

- Press  for the first unit in the LOOPER.



- This starts recording.



Using the looper

- Recording stops and loop playback starts.

If the recording time is set to "MANUAL"

Loop playback will start when you press  again or when the maximum recording time is reached.

If the recording time is set to a musical note

Loop playback will start when the set recording time is reached.



HINT

- See P39 for how to set the LOOPER recording time.
- During phrase recording and playback, switching to MEMORY mode will not interrupt it.

NOTE

- During rhythm playback, recording will start after the precount.
- Changing a patch will stop phrase recording and playback. Moreover, this will delete the phrase recording data.
- During rhythm playback, quantization is enabled so even if the recording ending time is not exact, the loop will automatically be adjusted so that loop playback stays in time.
- Changing the tempo of a RHYTHM during loop playback will erase the recorded phrase.

Overdubbing a recorded phrase

- During loop playback, press  for the first unit in the LOOPER.



Stopping loop playback

With 1-unit looper

- During loop playback, press  twice for the unit using the looper.



- This stops the playback.



Using the looper

With 2-unit looper

- During loop playback, press  for the second unit in the LOOPER.




- This stops the playback.



■ Deleting phrases

With 1-unit looper

- When loop playback is stopped, press and hold  for the unit using the looper.



- This deletes the phrase.



With 2-unit looper

- When loop playback is stopped, press  for the second unit in the LOOPER.




- This deletes the phrase.



Setting the looper

■ Setting the looper recording time


- Turn  for the unit using the looper.



NOTE

- The setting options include MANUAL and 1–64 quarter notes.
- The recording time for the mono looper is from 1.5 to 80 seconds (40 seconds when UNDO is ON).
- The recording time for the stereo looper is from 1.5 to 40 seconds (20 seconds when UNDO is ON).
- Settings that will not fit in the recording time will be adjusted automatically.
- Changing the recording time will delete the recorded data.

■ Setting the UNDO function

- Turn  for the unit using the looper to set it to ON/OFF.



NOTE



When UNDO is ON, the recording time will become as follows.

- Mono looper: 40 seconds
- Stereo looper: 20 seconds



Using the UNDO and REDO functions

If UNDO is ON, you can undo the last overdub. You can also use the REDO function to restore the phrase that the UNDO function deleted.

With 1-unit looper


To undo an overdub, press  for one second during playback. To restore the deleted phrase, press  for one second again.

With 2-unit looper

To undo an overdub, press  for the first unit twice during playback. To restore the deleted phrase, press  twice again.

Using the looper

■ Setting how loop playback stops

- Turn  for the unit using the looper.



STOP

Stop playback immediately.


FINISH

Play to the end and then stop.

FADE OUT

Stop after fading out.

■ Adjusting the looper volume

- Turn  for the unit using the looper.



NOTE


The setting range is 0–100.

Using the pedal

Using a connected pedal

■ Setting up the connected pedal


You can set a pedal effect to be assigned to the connected pedal.

- Press  to open the MENU screen.




- Turn  to select EX PDL.



- Press  to open the EXT PEDAL screen.



- Turn  to turn the connected pedal ON/OFF.



HINT

When EXT PEDAL is ON, you can use a pedal effect.

Using the tap tempo function

Loopers, rhythms, delays and some modulation effects can be synchronized to the tempo.


To synchronize, first select an effect that has a parameter that can be synchronized and set that parameter (Time or Rate, for example) to a note value (♩ or ♪).




Enabling tap tempo

- Press and hold  in STOMP or MEMORY mode.




- Press  to open the TAP TEMPO screen.




Setting the tempo


- Press  at least twice at the desired tempo.



- This sets the tempo.




HINT


You can also turn  for the center unit to adjust the tempo.

Using the tap tempo function / Restoring default settings and patches

Ending tap tempo setting

- Press  when the TAPTEMPO screen is open.

Restoring default settings and patches

- While pressing , set the POWER switch to ON.



- Turn  to select YES.



HINT

Select NO to cancel initialization.



- Press  to initialize.



- "Complete!" will appear on the display when initializing completes.




HINT

Executing the All Initialize function will restore all the settings of the **B3n**, including its patches, to factory defaults. Do not use this function unless you are certain that you want to do this.

Updating the firmware


Checking the firmware version


- Press  to open the MENU screen.



- Turn  to select VER.



- Press  and check the version.




Updating the firmware

■ To download the latest firmware

Visit the ZOOM Website (<http://www.zoom.co.jp/>).

- Connect the **B3n** to a computer using a USB cable.



- While pressing both  and , set the POWER switch to ON.



- Launch the version update application on your computer, and execute the update.



NOTE

Do not disconnect the USB cable during the update.

HINT

See the ZOOM website for instructions about how to use the application.



- "Complete!" will appear on the display when updating completes.



- Set the POWER switch to OFF.

HINT

Updating the firmware version will not erase saved patches.

Troubleshooting

No sound or very low volume

- Confirm that the POWER switch is set to "ON".
- Check the connections (→P4–5).
- Adjust the patch level (→P17).
- Adjust the master level (→P22).
- If you are using the expression pedal to adjust the volume, adjust the pedal position until the volume level is suitable.

There is a lot of noise

- Check shielded cables for defects.
- Use only a genuine ZOOM AC adapter.

An effect is not working

- If limits on effect processing capacity, the number of units or the amount of resources used are exceeded, effects will be bypassed and the following message will appear (→P9).

PROCESS OVERFLOW

Expression pedal does not work well

- Confirm the setting of the connected pedal (→P41).

Rhythm List

No.	PatternName	TimSig
1	GUIDE	4/4
2	8Beats1	4/4
3	8Beats2	4/4
4	8Beats3	4/4
5	16Beats1	4/4
6	16Beats2	4/4
7	16Beats3	4/4
8	Rock1	4/4
9	Rock2	4/4
10	Rock3	4/4
11	ROCKABLY	4/4
12	R'n'R	4/4
13	HardRock	4/4
14	HeavyMtl	4/4
15	MtlCore	4/4
16	Punk	4/4
17	FastPunk	4/4
18	Emo	4/4
19	TomTomBt	4/4
20	Funk1	4/4
21	Funk2	4/4
22	FunkRock	4/4
23	JazzFunk	4/4

No.	PatternName	TimSig
24	R&B1	4/4
25	R&B2	4/4
26	70s Soul	4/4
27	90s Soul	4/4
28	Motown	4/4
29	HipHop	4/4
30	Disco	4/4
31	Pop	4/4
32	PopRock	4/4
33	IndiePop	4/4
34	EuroPop	4/4
35	NewWave	4/4
36	OneDrop	4/4
37	Steppers	4/4
38	Rockers	4/4
39	Ska	4/4
40	2nd Line	4/4
41	Country	4/4
42	Shuffle1	4/4
43	Shuffle2	4/4
44	Blues1	4/4
45	Blues2	4/4
46	Jazz1	4/4

No.	PatternName	TimSig
47	Jazz2	4/4
48	Fusion	4/4
49	Swing1	4/4
50	Swing2	4/4
51	Bossa1	4/4
52	Bossa2	4/4
53	Samba1	4/4
54	Samba2	4/4
55	Breaks1	4/4
56	Breaks2	4/4
57	Breaks3	4/4
58	12/8 Grv	12/8
59	Waltz	3/4
60	JzWaltz1	3/4
61	JzWaltz2	3/4
62	CtWaltz1	3/4
63	CtWaltz2	3/4
64	5/4 Grv	5/4
65	Metro3	3/4
66	Metro4	4/4
67	Metro5	5/4
68	Metro	

Specifications

Effect types	80 types
Number of simultaneous effects	7
Number of user patches	150
Sampling frequency	44.1 kHz
A/D conversion	24-bit with 128x oversampling
D/A conversion	24-bit with 128x oversampling
Signal processing	32-bit
Frequency characteristics	20-20 kHz +1 dB, -3 dB (10 kΩ load)
Display	128x32 dot-matrix LCDs (3)
Input INPUT	Standard monaural phone jack Rated input level: -20 dBu Input impedance(line) : 470 kΩ
AUX IN	Stereo mini jack Rated input level: -10 dBu Input impedance(line) : 10 kΩ
Output R	Standard monaural phone jack Maximum output level: +5 dBm (with output load impedance of 10 kΩ or more)
L/MONO/PHONES	Standard stereo phone jack (combined line/headphone) Maximum output level: Line +5 dBm (with output load impedance of 10 kΩ or more) Headphones 15 mW +15 mW (into 32 Ω load)
Equivalent input noise	119 dBu
Noise floor (residual noise)	-100 dBu
Control input	FP02 input
Power	AC adapter DC 9 V (center minus plug), 500 mA (ZOOM AD-16)
Dimensions	B3n 181 mm(D) X 234 mm(W) X 58 mm(H)
USB	USB MIDI USB Micro-B
Weight	B3n 1.28 kg
Options	FP02 expression pedal

• 0 dBm=0.775 Vrms